

Caution lights



Indicates APU fault, APU fire or compartment overheat.

Applicable ECL APU FIRE or APU failure.

Remarks Also illuminates during overspeed and fire test and APU generator off-line condition.