

Emergency Descent

Checklist recognition

- Crew oxygen masks
- Thrust levers idle
- Autopilot disengaged
- EMER spoilers extended
- Establish approximately 10 to 12° nosedown pitch attitude
- Descend at M_{MO}/V_{MO}

Cabin altitude warning activates or cabin altitude exceeds 9,400 ft



- Descend
- Maintain pitch attitude until reaching M_{MO}/V_{MO}
 - Adjust pitch attitude to maintain M_{MO}/V_{MO} – trim
 - Accomplish Emergency Descent checklist when able

- Notify ATC of emergency descent
- Ask for minimum safe altitude in this area and current altimeter setting

Look aft in cabin to check on passengers

- Level off at altitude not requiring mask
- Spoilers retracted
 - Power as required to maintain safe speed

Emergency Descent